


CC598 Support Package



Software Release Bulletin



Level 750

Control Data Corporation

June, 1990

Introduction

This package contains one floppy disk (part number 10322177 Rev D) and this Software Release Bulletin. The floppy disk is a MS-DOS bootable disk containing Level 750 Console Software and the programs used to assemble and maintain the CC598A and CC598B System Consoles and the CC598C LCN Network Maintenance Station.

Copyright/Proprietary Software

This disk contains software copyrighted by Zenith Data Systems and Microsoft Corporation licensed to Control Data as well as Control Data proprietary software. Duplication in whole or part is prohibited. Additional copies may be ordered from SMD.

CSW Support

Any problem with the console software should be reported on a PSR under the ident CSW. Specify the nature of the problem and include the level number on each PSR.

Any problem with the media or the package contents should be reported to Software Manufacturing and Distribution (SMD). A report form "The Software Manufacturing and Distribution Critique Letter" accompanies each disk. To order a replacement disk, please complete this form. Be sure to include a description of the problem and your mailing address. Send the form with the defective disk to SMD so that a replacement disk can be sent to you.

A replacement disk may also be ordered by phone, by calling 612-482-3409.

Any problem with the contents of this SRB should be reported to Central Software Support, 1-800-345-6628 US/Canada and 1-612-482-3434 other Countries.

Manual vs SRB

Where there is a difference between the information contained in this document and the 19003 System Console Operations and Maintenance Manual, the information contained here takes precedence.

New Features

Cyber 960 'S' Support.

The console software now supports the Cyber 960 'S' model system (Cyber 960 with an AT478D IOU).

Keyboard Hang.

The apparent 'keyboard hang' caused by simultaneously striking the Ctrl-F1 and F2 keys has been corrected.

Disappearing Cursor.

With previous releases and newer Paradise Video boards, it was possible for the cursor to disappear after exiting from the Console Utilities menu.

Table of Contents

Page	Topic
1	Introduction
1	New Features
2	Console Software Installation
2	Conventions
2	How to Boot the Support Disk
3	Hard Disk Initialization
4	Wren III Low Level Formatting
5	Hostess Diagnostics
6	System Hardware Setup
8	HDI Part 1 Instructions

Console Software Installation

To install the Console Software on the hard disk, type **INSTALL** and press the **ENTER** key.

When the CDC logo appears on the screen, the installation is complete.

NOTE: If an IOU is not attached to the console, an error message is displayed. This is normal.

Conventions

The term 'console' refers to any model of the CC598.

When the word 'press' is used, it means to press the named key(s).

When the word 'press' precedes a string of key names that are separated by hyphens, it means to press the keys simultaneously.

When the word 'type' is used, it means to type the word following.

How to Boot the Support Disk

With power applied to the console, insert the Support disk into the floppy drive and latch the door. Press the **Ctrl-Alt-Ins** keys. The console will display:

```
MFM-200 Monitor, Version X.X
Memory Size: 640K Bytes
Enter ? for help
->
```

Type **BF** and press the **ENTER** key. The following screen will appear.

```
CC598 Support Package

Refer to the documentation accompanying this disk for usage
information.

Quick Reference:
Console Software Installation - Type INSTALL
Hard Disk Initialization - Type HDI
Wren III Low Level Format - Type LOW
Hostess Diagnostics - Type HOST
Advanced Emulation Package - Type AEP

All entries must be followed by pressing the ENTER key
```

Enter the command for the procedure that you wish to execute. After entering the procedure command, a set of instructions will be displayed on the screen. Follow these instructions.

NOTE: If your console is a B or C model and you have replaced the hard disk, disregard the 'controller is bad' error message when first applying power to the console before executing the HDI procedure.

Procedure Hard Disk Initialization



WARNING

Prior to executing this procedure, examine the System Configuration information. Refer to the section on System Hardware Setup.
This procedure will destroy all data on the hard disk!

To execute the Hard Disk Initialization, type **HDI** and press the **ENTER** key. The following informational display will be presented.

Hard Disk Initialization Procedures for the CC598-A/B/C Consoles

The CC598 console requires a two part process in order to prepare the disk.

A re-boot is required between the parts. To re-boot press the Ctrl-Alt-Ins keys.

When you are ready, press any key for the detailed instructions. The screen shown below will appear.

Hard Disk Initialization Procedures for the CC598-A/B/C Consoles

Part One:

For a CC598A type "A1" Then follow the instructions in the SRB accompanying this disk.

For a CC598B/C Console type "B1"

Part Two:

For a CC598A Console type "A2"

For a CC598B Console type "B2"

For a CC598C Console type "C2"

The instructions begin on page 8.

Select the procedure for your console model and type the command for the part that you are going to execute. All parts must be executed and be executed in order. If your console is a B or C model, disregard the 'not a bootable partition' error message after executing Part 1.

Procedure Wren III Low Level Format

There are no specific ground rules for when this procedure should be executed. Think of the Low Level format the same way that you think of formatting a CYBER disk and use it accordingly. Generally speaking, try this procedure on the disk prior to replacing it. It may fix the problem.



WARNING

This procedure performs a low level format on the Wren III. All information stored on or about the disk is lost.

The hard disk must be initialized using HDI after executing this procedure.

To execute the Wren III Low Level Format procedure, type **LOW** and press the **ENTER** key. The following informational screen will be presented.

Wren III Low Level Format Routine

This procedure performs a low level format on the Wren III. All information stored on or about the disk is lost.

Note: The light on the Wren III will not be on during this operation. **DO NOT** interrupt the formatting operation or the console will be unusable.

Press any key to start the format. The following format display will appear on the screen.

```
Version 2.13 - 9 November 1987
Controller is Generic
Base I/O Port Address is: 330
DMA Channel is: 1
Common Command Set Enabled
```

```
1 port: 340h
2 rt10-at
3 dma:hsdma
RT10-AT Adapter Assumed
4 dmachan: 5
5 tfr
tdr CDB is 00 00 00 00 00 00
Status: 00H
6 fd
fd CDB is 04 00 00 00 00 00
```

The following display will appear when the formatting is complete.

Common Command Set Enabled

```
1 port: 340h
2 rt10-at
3 dma:hsdma
RT10-AT Adapter Assumed
4 dmachan: 5
5 tfr
tdr CDB is 00 00 00 00 00 00
Status: 00H
6 fd
fd CDB is 04 00 00 00 00 00
Data Written:
Status: 00H
7 quit
```

A>

Procedure Hostess Diagnostics

To execute the Hostess Network Adapter diagnostics, type **HOST** and press the **ENTER** key.

Enter the following information as prompted by the diagnostic.

Hostess board base address:	Enter 140
System Clock Speed:	Select 2
Number of Ports:	Enter 8

Note: For additional information and explanations of any error message displayed, refer to the HOSTESS Multiport Network Adapter User's Guide which was shipped with your console.

As the diagnostic runs, you will be directed to install the test plug that is included in the Multiport Adapter package. Install the test plug on the port as you are directed.

Utility Disk Directory Structure

The disk is divided into five directories. Each directory contains the software necessary to perform a unique function. The five directories are:

- BIN:** The BIN directory contains MS-DOS programs that are common to all of the procedures.
- HDI:** The HDI directory contains the procedures used to initialize the hard disks in the consoles.
- LOW:** The LOW directory contains the software and procedures necessary to perform a low level format on the CC598A's Wren III-SCSI hard disk.
- HOST:** The HOST directory contains a copy of the HOSTESS diagnostics for the HOSTESS Multiport Network Adapter used in the CC598A and CC598B consoles.
- CSW:** The CSW directory contains the CC598A and CC598B Console Software.

Procedure System Hardware Setup

The following steps describe how to reboot and reconfigure the console. With power applied to the console, insert the Support disk into the floppy drive and latch the door.

Press the **Ctrl-Alt-Ins** keys. The console will display:

```
MFM-200 Monitor, Version X.X
Memory Size: 640K Bytes
Enter ? for help
->
```

Type **SETUP** and press the **ENTER** key.

Depending on your console type, one of the following displays will appear. Use the arrow keys to move the cursor, the space/backspace to select the values and the ESC key to exit when you are done. After pressing the ESC key, follow the directions shown at the bottom of the display.

System Hardware Setup/Configuration Program			
Time: 01:01:00		Operating Speed: Slow FAST Smart	
Date: 06/16/89		Hard Disk Drive 0: -NOT PRESENT-	
	Base	Extended	EMS
Main RAM:	640K	0K	256K
Add-On RAM:	0K	0K	---
Total:	640K	0K	256K
Floppy Drive 0: 5-1/4" 1.2M			
Floppy Drive 1: -Not Present-			
Boot Drive: Floppy Disk Drive 0			
Serial Port 1 (com1): Enable			
Serial Port 2 (com2): Enable			
Video Display: Enhanced Graphics			
Video Refresh Rate: 50Hz 60Hz			
Enter Current Time as HH:MM:SS in 24 Hour Format			
Use space/backspace to select values, Arrows to move, ESC when done			

CC598A Configuration

NOTE: The -Not Present- Indication shown here for Hard Disk Drive 0 is normal, since the CC598A console uses a SCSI drive.

System Hardware Setup/Configuration Program

Time: 01:01:00

Date: 06/16/89

	Base	Extended	EMS
Main RAM:	640K	0K	256K
Add-On RAM:	0K	0K	---
Total:	640K	0K	256K

Floppy Drive 0: **5-1/4" 1.2M**

Floppy Drive 1: -Not Present-

Boot Drive: **Hard Disk Drive 0**

Serial Port 1 (com1): Enable

Serial Port 2 (com2): Enable

Video Display: **Enhanced Graphics**

Video Refresh Rate: 50Hz 60Hz

Enter Current Time as HH:MM:SS in 24 Hour Format

Use space/backspace to select values, Arrows to move, ESC when done

Operating Speed: Slow **FAST** SmartHard Disk Drive 0: **Drive Type 43**

Media Type: N/A		
Cylinders:	989	Heads: 5
Ship Zone:	988	Sectors: 17
Precomp:	0	Capacity: 43M

Hard Disk Drive 1: **-NOT PRESENT-**

Media Type: N/A		
Cylinders:		Heads:
Ship Zone:		Sectors:
Precomp:		Capacity:

CC598B and CC598C Configuration.

NOTE: The displays shown are generic. The location of the items may be different on your console. This is due to the different revision levels of the BIOS ROM installed in the consoles. However, make certain that the highlighted items in these displays match what is selected on your console.

CC598A HDI Instructions Part 1

Introduction

This procedure partitions the hard disk into three CIP partitions. The MS-DOS utility, PART, is used to accomplish the partitioning. This utility is graphic/windows oriented. Therefore, most of the displays are windowed inside of each other.

Execution

After typing 'A1' from the HDI display, the following screen will appear.

Part - Hard Disk Partitioning Utility
Copyright (c) 1989, Zenith Data Systems Corporation

The part utility helps you to change the arrangement of the MS-DOS Partitions on your hard disk drive. PART displays a table showing the types of each partition, the start cylinder, the end cylinder and the amount of disk space allocated to each partition.

CAUTION: Using PART can destroy all files on your hard disk drive. Do not use PART until you have transferred copies of your hard disk files to floppy disks.

Press ENTER or ESC to continue...

Press the Enter Key

The display will be replaced with the following display. This display is the main display and is active during the remainder of this procedure. Additions will be made to this display as we proceed.

PART - Hard Disk Partitioning Utility
Copyright (c) 1989, Zenith Data Systems Corporation
Version 3.30.06

Current hard disk unit selected (logical/physical) = 1 (80h)
Current Boot partition = NONE, Maximin Cyl/Heads/Sectors = 982/ 7/26

Select next hard disk partition
Display current hard disk partition
Add a MS-DOS hard disk partition
Delete a MS-DOS hard disk partition
Change the default MS-DOS boot partition
Exit PART and return to MS-DOS

Move to selection with arrow keys, press ENTER to Select or ESC to Quit
Main Display


HDI Part 1 Instructions continued...

Press the Down Arrow key

You will notice that the 'Select next hard disk unit' option is highlighted. Press the down arrow key until the 'Add a MS-DOS hard disk partition' option is highlighted.

Press the Enter key

Pressing the ENTER key selects the 'Add a MS-DOS hard disk partition' option and causes the following window to open.




```

Add a Primary MS-DOS partition (BOOTABLE)
Add a Extended or Logical MS-DOS partition (NON-BOOTABLE)

```

Press the Enter key

The 'Add a Primary MS-DOS partition (BOOTABLE)' option is highlighted. Pressing the ENTER key selects this option and causes the following window to open.




```

Enter size of new PRIMARY partition in cylinders or ESC to Quit [ 982]

```

Enter 360

This is the number of cylinders for the first partition. The window will change to:



```

Enter size of new PRIMARY partition in cylinders or ESC to Quit [ 360]

```

Press the Enter key


Pressing the ENTER key causes the first partition to be 360 cylinders. The screen will return to the main display as shown on page 8.

Press the Down Arrow key

You will notice that the 'Select next hard disk unit' option is highlighted. Press the DOWN ARROW key until the 'Add a MS-DOS hard disk partition' option is highlighted.

Press the Enter key

Pressing the ENTER key selects the 'Add a MS-DOS hard disk partition' option and causes the following window to open:




```

Add a Primary MS-DOS partition (BOOTABLE)
Add a Extended or Logical MS-DOS partition (NON-BOOTABLE)

```

Press the Enter key

The 'Add a Primary MS-DOS partition (BOOTABLE)' option is highlighted. Pressing the ENTER key selects this option and causes the following window to open:




```

Enter size of new PRIMARY partition in cylinders or ESC to Quit [ 622]

```

Enter 311

This the numbers of cylinders for the second partition. The window will change to:



```

Enter size of new PRIMARY partition in cylinders or ESC to Quit [ 311]

```

**HDI Part 1 Instructions
continued...**

Press the Enter key

Pressing the ENTER key causes the second partition to be 311 cylinders. The screen will return to the main display as shown on page 9.

Press the Down Arrow key

You will notice that the 'Select next hard disk unit' option is highlighted. Press the DOWN ARROW key until the 'Add a MS-DOS hard disk partition' option is highlighted.

Press the Enter key

Pressing the ENTER key selects the 'Add a MS-DOS hard disk partition' option and causes the following window to open:

Add a Primary MS-DOS partition (BOOTABLE)
Add a Extended or Logical MS-DOS partition (NON-BOOTABLE)

Press the Enter key

Pressing the ENTER key selects this option and causes the following window to open:

Enter size of new Primary partition in cylinders or ESC to Quit [311]

Press the Enter key

Pressing the ENTER key causes the third partition to be 311 cylinders. The screen will return to the main display as shown on page 8.

Press the Down Arrow key

You will notice that the 'Select next hard disk unit' option is highlighted. Press the DOWN ARROW key until the 'Change the Default MS-DOS Boot partition' option is highlighted.

Press the Enter key

Pressing the ENTER key selects the 'Change default MS-DOS boot partition' option and causes the following window to open:

Select next hard disk unit				
Partition	Start	End	Cyls	Size(Mb)
1) DOS(16)	0	359	360	33.53
2) DOS(16)	360	670	311	28.98
3) DOS(16)	671	981	311	28.98
4) Un-used				
No default BOOT partition				

Press the Enter key

You will notice that the first line of the window, 1)DOS(16).., is highlighted. By pressing the ENTER key, this partition is selected as the boot partition.

HDI Part 1 Instructions continued...

Examine the display

Notice that the 'Current Boot Partition = None' has
changed to 'Current Boot Partition = 1'

PART - Hard Disk Partitioning Utility
Copyright (c) 1989, Zenith Data Systems Corporation
Version 3.30.06

Current hard disk unit selected (logical/physical) = 1 (80h)
Current Boot partition = 1, Maximin Cyl/Heads/Sectors = 982/7/26

Select next hard disk partition
Display current hard disk partition
Add a MS-DOS hard disk partition
Delete a MS-DOS hard disk partition
Change the default MS-DOS boot partition
Exit PART and return to MS-DOS

Move to selection with arrow keys, press ENTER to Select or ESC to Quit

Verification

The following sequence is used to verify that the
partitioning was successful.

Press the Down Arrow key

Press the DOWN ARROW key until the 'Display current
hard disk partition' option is highlighted.

Press the Enter key

Pressing the ENTER key selects the options and causes the
following window to open:

Select next hard disk unit					
Partition	Start	End	Cyls	Size(Mb)	
1) DOS(16)	0	359	360	33.53	
2) DOS(16)	360	670	311	28.98	
3) DOS(16)	671	981	311	28.98	
4) Un-used					

Press the Enter key

Before pressing the ENTER key. Make sure that the
display on the screen matches the screen shown above.
Whether correct or incorrect, you must press the ENTER
key to proceed.

**HDI Part 1 Instructions
continued...****If Correct...**

Press the Down Arrow key

Press the DOWN ARROW key until the 'Make change and REBOOT the system' option is highlighted.

Press the Enter key

Pressing the ENTER key selects the option and causes the following window to open:

Are you sure that you want to (Y/N) :

Press the Y key

After pressing the Y key, the system will reboot. Proceed to HDI Part 2 on page 3.

If All is NOT Correct...

Press the Down Arrow key

Press the DOWN ARROW key until the 'Abort all changes and EXIT to MS-DOS' option is highlighted.

Press the Enter key

Pressing the ENTER key selects the option and causes the window shown on the next page to open.

Are you sure that you want to Quit (Y/N) :

Press the Y key

After pressing the Y key, the system will return to the A> prompt. Since you aborted the PART utility, no changes have been made to the hard disk. To continue, start the HDI procedure over again by pressing the Ctrl-Alt-Del key.

Note : The PART utility records information on the hard disk. If you execute this utility and find out later that something is incorrect, you must run the procedure LOW before attempting to re-execute this procedure.